

Assembly Directions for *Comfo & Cozi Love Seat*

PCLS4800 , #PZLS4800



PACKAGE CONTENTS


- 1 Back Assembly
- 1 Seat Assembly
- 2 Arm Assemblies
- 1 Cross Brace
- 1 Hardware Package

HARDWARE PACKAGE

- 3 • ¼" x 3" Allen Head Bolts
- 2 • ¼" x 3½" Allen Head Bolts
- 2 • ¼" x 4½" Allen Head Bolts
- 7 • ¼" Flange Nuts
- 4 • 2½" Bugle Head Sq. Drive Screws

TOOLS NEEDED

- 7/16" Wrench
- Hammer
- Allen Wrench (included)



Use to measure bolts

Step #1

Fasten the Arm and Leg Assembly to the Seat and Back using $\frac{1}{4}$ " Allen Head Bolts (size is specified below). Using a hammer, firmly tap the Bolts until they are flush with the poly surface. Securely tighten using $\frac{1}{4}$ " Flange Nuts.

$\frac{1}{4}$ " x 3" Allen Head Bolt

$\frac{1}{4}$ " x 3 $\frac{1}{2}$ " Allen Head Bolt

$\frac{1}{4}$ " x 4 $\frac{1}{2}$ " Allen Head Bolt



Step #2

Turn the chair on the other side and repeat Step #1.

$\frac{1}{4}$ " x 3" Allen Head Bolt

$\frac{1}{4}$ " x 3 $\frac{1}{2}$ " Allen Head Bolt

$\frac{1}{4}$ " x 4 $\frac{1}{2}$ " Allen Head Bolt



Step #3

Set Love Seat upright, and fasten Cross Brace using 2 $\frac{1}{2}$ " Bugle Head Sq. Drive Screws.

NOTE: Make sure top of Cross Brace is flush with top of Leg Brace.

2 $\frac{1}{2}$ " Screws

