

#2 Square Drive Bit (not Included)

52" Allen Key (Included)


For Burner Asssembly Tools. See page 8 in the burner Manual


Assembly Instructions






DETAIL A SCALE 1:5






Choose a flat surface to assemble your furniture.
 Attach (C) Backside Panel to (A) &(D) End Panels using 12-(G) 2" Screws in the predrilled holes.



Inside Skirting


3. Note. Push End Panels against

4.Attach 1 side of the (F) Floor to backside using 3-(H) $\frac{5}{16}$ "X1 $\frac{1}{2}$ " Wafer Bolts.



5. Attach (B) Front Panel with the Door to (A) & (D) End panels using 12-(G) 2" Screws in predrilled holes.

6. Attach Front Side of (F) Floor to (B) Front Side Panel using 3-(H) 5/16"X 1 1/2" Wafer Bolts.



DETAIL D SCALE 1:10


Lumin Fire Table 79" Rectangular Bar Height


FINE OUTDOOR FURNITURE



Assembly Instructions

8.Position (E) Top on assembled Base, align with marks on Top. Attach Top using 16-(G) 2" Screws in predrilled holes.





9. Read, Understand and follow "Burner Instruction Manual" for safe operation.

- 10.Follow instructions in "Burner Installation Section" starting on page 6 in the manual. Get someone to help attach Igniter, and Burner Control, to the Control Plate.
- 11. Assemble Wind Guard. "Always keep Wind Guard in place with lighted burner"!!!!!!

