


Tools Required
#2 Square Drive Bit (not Included)


\$\frac{5}{32}\text{" Allen Key (Included)}\$

For Burner Asssembly Tools. See page 8 in the burner Manual


## Fire Table Parts List Α Left End Panel with Control Panel 1 В Front Panel with Door 1 С Backside Panel Right End Panel D 1 1 Е Top F Floor 40 G 2" Stainless Steel Screws 6 5/16"X1 ½"Stainless Steel Wafer Bolt


















Choose a flat surface to assemble your furniture.
 Attach (C) Backside Panel to (A) &(D) End
Panels using 8-(G) 2" Screws in the predrilled
holes.




 -3. Note. Push End Panels against inside Skirting when installing Screws.




4.Attach 1 side of the (F) Floor to backside using 3-(H) 5/16"X1 1/2" Wafer Bolts.



5. Attach (B) Front Panel with the Door to (A) & (D) End panels using 8-(G) 2" Screws in predrilled holes.



6. Attach Front Side of (F) Floor to (B) Front Side Panel using 3-(H) 5/16"X 1 1/2" Wafer Bolts.





DETAIL C SCALE 1:10

Lumin Fire Table 79" Rectangular Dining Height



8.Position (E) Top on assembled Base, align with marks on Top. Attach Top using 16-(G) 2" Screws in predrilled holes.





## 9.Read, Understand and follow "Burner Instruction Manual" for safe operation.

- 10. Follow instructions in "Burner Installation Section" starting on page 6 in the manual. Get someone to help attach Igniter, and Burner Control, to the Control Plate.
- 11. Assemble Wind Guard. "Always keep Wind Guard in place with lighted burner"!!!!!!

