



SEASIDE CASUAL

(42,59) 48In & 60In Salem Dining Tables rev. C

Parts List:

- (1) Table Top Assembly
- (2) Leg Assemblies
- (2) Leg Stretchers
- (2) Long Aprons
- (2) Short Aprons



Hardware:

- (16) 3" Hex 1/4" Lags
- (10) 3/4" Pan Head Screws
- (2) Thumb Screws
- (59 Only) (18) 3/4" Pan Head Screws

Tools Required:


- Phillip's Head Screwdriver
- 4MM Allen Wrench (Included)

Assembly Instructions

Step One: Set Up

READ ENTIRE INSTRUCTIONS BEFORE BEGINNING! Carefully remove contents from box. Make sure that all parts and hardware are included.

Step Two: Leg Stretcher Assembly



Place Leg Stretcher in between both Leg Assemblies. Align pre-drilled holes on Leg Stretcher to Leg Assemblies. Attach using (2) 3" Hex 1/4" Lags (Left Picture). Repeat process on all sides.

Step Three: Apron Assembly



Attach Short Apron to Long Apron using (4) 3" Hex 1/4" Lags (Left Picture).

Step Four: Base Assembly

Place Apron Assembly on to the Leg Assembly and secure using (4) 3“ Hex 1/4” Lags (Right Picture).



Step Five: Final Assembly

Lift Base Assembly and place square on to table top. Align Apron ends and sides to the center of the table top. Attach table top to the base using (10) 3/4” pan head screws. (59 Only) use (18) 3/4” pan head screws.

