




Tools Required


5/32 Hex Key (Included)



9/16" Wrench (Not Included)



#2 Square Drive Bit (Not Included)




Cordless Drill (Not Included)




Hardware

- 2 - 3 1/2" Stainless Wafer Bolts
- 2 - 2 1/2" Stainless Wafer Bolts
- 4 - 2" Stainless Wafer Bolts
- 4 - 3/8" Nuts
- 4 - Washers
- 8 - 2" Screws
- 1 - 5/32 Hex Key

Swivel Base x1




Seat Assembly x1





Back Assembly x1




Armrest's x2




Lintels x2




1. Attach Armrest Assemblies to Swivel Base using 2 Nuts & 2 Washers per side.



Note: (No Aluminum Showing on Front of Glider Base)




2. Attach Back Assembly to Seat Assembly using 1 - 2" Wafer Bolt per side, Be sure to match all letters, tighten Wafer Bolts with included Hex Key.



2" Wafer Bolt

3. Slide Seat & Back Assembly between Armrests & attach to Armrests using 1 - 3 1/2" Wafer Bolt 1 - 2 1/2" Wafer Bolt & 1 - 2" Wafer Bolt per side, be sure to match all letters, tighten Wafer Bolts with included Hex Key.




2 1/2" Wafer Bolt

3 1/2" Wafer Bolt

2" Wafer Bolt

4. Attach Lintels to Armrest assemblies using 4 - 2" Screws per side, be sure to match all letters.



2" Screw



2' Adirondack Swivel Glider Assembly Instructions

12/18/ 2024

R.M.