




Hardware


- 2 - 5/16" x 3 1/2" Stainless Wafer Bolts
- 2 - 5/16" x 2 1/2" Stainless Wafer Bolts
- 4 - 5/16" x 2" Stainless Wafer Bolts
- 4 - 2" Screws
- 1 - 5/32" Hex Key

Tools Required



5/32 Hex Key (Included)




#2 Square Drive Bit
(Not Included)





Cordless Drill
(Not Included)




Back Assembly x1



Armrest's x2



1. Attach Back Assembly to Seat Assembly using 1 - 2" Wafer Bolt per side, Tighten Wafer Bolts with included Hex Key, Be sure to match all Numbers.



2" Stainless Wafer Bolt

2. Attach Armrest Assemblies to Seat Assembly & Back Assembly using 1 - 3 1/2" Wafer Bolt, 1 - 2 1/2" Wafer Bolt, & 1 - 2" Wafer Bolt per Armrest Assembly, tighten Wafer Bolts with included Hex Key. Be sure to match all Numbers.




2 1/2" Stainless Wafer Bolt

2" Stainless Wafer Bolt

3 1/2" Stainless Wafer Bolt

3. Install 2 - 2" Screws per side from inside of seat in predrilled holes.



2" Screw



2 Classic Poly Bench Assembly Instructions

01/17/ 2025

R.M.