



Hardware


- 2 - 5/16" x 3 1/2" Stainless Wafer Bolt
- 2 - 5/16" x 2 1/2" Stainless Wafer Bolt
- 4 - 5/16" x 2" Stainless Wafer Bolt
- 4 - 3/8" Lock Nuts
- 4 - Washers
- 12 - 3" Screws
- 32 - 2" Screws
- 1 - 5/32 Hex Key

Tools Required


5/32 Hex Key (Included)




#2 Square Drive Bit
(Not Included)




9/16" Wrench
(Not Included)




Cordless Drill
(Not Included)




Seat Assembly x1




Back Assembly x1



Glider Base x2




Armrest's x2




Bearing Arm Supports x2




Back Crosspiece Short x1




Front Crosspiece Long x1




Lintels x2




1. Attach Front Crosspiece (Long) to Glider Base's using 4 - 2" Screws and 3 - 3" Screws per Side, Be sure to match all letters.



2. Attach Back Crosspiece (Short) to Glider Base's using 4 - 2" Screws and 3 - 3" Screws per side, Be sure to match all letters.



3. Attach Bearing Arm Support's to Glider Base using 4 - 2" Screws per side, Be sure to match all letters.




2' Classic Poly Glider Assembly Instructions

12/18/ 2024


R.M.




4. Attach Armrest Assemblies to Glider Base using 2 - Washers & 2 Nuts per side, Be sure to match all letters.



5. Attach Back Assembly to Seat Assembly using 1 - 2" Wafer Bolt in top hole per side, Be sure to match all letters. Tighten Wafer Bolts with included Hex Key.



7. Attach Lintels to Armrest Assemblies using 4 - 2" Screws per side, Be sure to match all letters.



6. Slide Seat & Back Assembly between Armrest's & install 1 - 3 1/2" Wafer Bolt 1 - 2 1/2" Wafer Bolt & 1 - 2" Wafer Bolt per side, Be sure to match all letters, Tighten Wafer Bolts with included Hex Key.



2' Classic Poly Glider Assembly Instructions

12/18/ 2024

R.M.