




Tools Required


5/32 Hex Key (Included)




9/16" Wrench
(Not Included)



#2 Square Drive Bit
(Not Included)



Cordless Drill
(Not Included)



Hardware

2 - 3 1/2" Stainless Wafer Bolts

2 - 2 1/2" Stainless Wafer Bolts


4 - 2" Stainless Wafer Bolts

4 - 3/8" Nuts


4 - Washers

8 - 2" Screws

1 - 5/32 Hex Key



Swivel Base x1



Seat Assembly x1


Back Assembly x1



Armrest's x2





Lintels x2



1. Attach Armrest Assemblies to Swivel Base using 2 Nuts & 2 Washers per side.

Note: (No Aluminum Showing on Front of Glider Base)



Nut

Washer


2. Attach Back Assembly to Seat Assembly using 1 - 2" Wafer Bolt per side, Be sure to match all letters, tighten Wafer Bolts with included Hex Key.

2" Wafer Bolt




3. Slide Seat & Back Assembly between Armrests & attach to Armrests using 1 - 3 1/2" Wafer Bolt 1 - 2 1/2" Wafer Bolt & 1 - 2" Wafer Bolt per side, be sure to match all letters, tighten Wafer Bolts with included Hex Key.

2 1/2" Wafer Bolt
3 1/2" Wafer Bolt



2" Wafer Bolt

4. Attach Lintels to Armrest assemblies using 4 - 2" Screws per side, be sure to match all letters.



2" Screw



2' Classic Swivel Glider Assembly Instructions

11/21/ 2024

R.M.