





4. Attach Armrests to Glider Base using 2-Washers & 2-Nuts per side, be sure to match all letters. "Assembly order is Armrest Assembly-Washer-Nut"



6. Attach Back Assembly to Seat Assembly using 4 - 2" Wafer Bolts, be sure to Match all letters, tighten Wafer Bolts with included Hex Key.





7. Attach Back-Seat Assembly to Armrests using


1 - 3 1/2" Wafer Bolt

1 - 2 1/2" Wafer Bolt &

1 - 2" Wafer Bolt per side, be sure to match all letters, tighten Wafer Bolts with included Hex Key.









4' Plain Poly Glider Assembly Instructions

11/13/ 2024

R.M.