



#### Tools Required


5/32 Hex Key (Included)



1/2" Wrench  
(Not Included)



#2 Square Drive Bit  
(Not Included)



Cordless Drill  
(Not Included)




#### Hardware

2 - 5/16" x 3 1/2" Stainless Wafer Bolt  
2 - 5/16" x 3" Stainless Wafer Bolts  
6 - 5/16" x 2" Stainless Wafer Bolts  
8 - 5/16" Nuts  
12 - Washers  
4 - 2" Screws  
4 - 1 1/2" Screws  
1 - Set Swing Chains  
1 - 5/32" Hex Key


#### Armrest Assemblies x2




#### Seat Assembly x1




#### Back Assembly x1




**1. Attach Back Assembly to Seat Assembly using 6 - 2" Wafer Bolts, Be sure to match all letters, Tighten Wafer Bolts with included Hex Key.**




**2. Attach Armrest Assemblies to each side using 1 - 3 1/2" Wafer Bolt 1 - 3" Wafer Bolt 2 - Washers & 2 Nuts per side. Be sure to match all letters Tighten Wafer Bolts with included Hex Key. Insert Bolts from inside out:**



**3. Install 2 - 2" Screws & 2 - 1 1/2" Screws per side.**



**4. Attach short end of Chain to back of Armrest assemblies & other end through screw eye to bottom of front upright using 4 Washers & 2 nuts per side.**



4' Plain Poly Swing Assembly Instructions

11/13/ 2024

R.M.