





5. Attach the 12 Back Slats to Back Assembly using 4 - 1 1/2" Screws per Slat.
Note: Numbers on Slats must Match
Numbers on Back Support Pc. To
ensure correct Slat placement.




using 6 - 2" Wafer Bolts, be sure to Match all letters, tighten Wafer Bolts with included Hex Key.

6. Attach Back Assembly to Seat Assembly

- 7. Attach Back-Seat Assembly to Armrests using
- 1 3 1/2" Wafer Bolt
- 1 2 1/2" Wafer Bolt &
- 1 2" Wafer Bolt per side, be sure to match all letters, tighten Wafer Bolts with included Hex Key.



8. Attach Lintels to Armrest Assemblies using 4 - 2" Screws per side, be sure to match all letters.





5' Adirondack Poly Glider Assembly Instructions

11/21/ 2024

R.M.