



- Hardware  
2 - 5/16" x 3 1/2" Stainless Wafer Bolts  
2 - 5/16" x 2 1/2" Stainless Wafer Bolts  
8 - 5/16" x 2" Stainless Wafer Bolts  
4 - Lock Nuts  
4 - Washers  
12 - 3" Stainless Steel Screws  
8 - 2 1/2" Stainless Steel Screws  
32 - 2" Stainless Steel Screws  
8 - 1/2" Stainless Steel Screws  
1 - 5/32 Hex key

Tools Required


5/32 Hex Key (Included)





#2 Square Drive Bit (Not Included)




Cordless Drill (Not Included)




9/16" Wrench (Not Included)




1. Attach Back Crosspiece (Short) and Front Crosspiece (Long) to Glider Base's Using 8 - 2" and 6 - 3" Screws per side, be sure to match all letters.





2. Attach Crosspiece Supports to Front-Back Crosspieces using 4 - 2" Screws per side, be sure to match all letters.



3. Attach Bearing Arm Supports to Glider Base using 4 - 2 1/2" Screws per side, Note: Install Aluminum facing towards back and down in Base Assembly. be sure to match all letters.



4. Attach Armrests to Glider Base using 2-Washers & 2-Nuts per side, be sure to match all letters.  
"Assembly order is Armrest Assembly-Washer-Nut"



Aluminum




5' Classic Poly Glider Assembly Instructions

11/12/ 2024


R.M.




5. Attach Headboard to Back Assembly using 8 - 1/2" Screws, be sure to match all numbers.




6. Attach Back Assembly to Seat Assembly using 6 - 2" Wafer Bolts, be sure to Match all letters, tighten Wafer Bolts with included Hex Key.



7. Attach Back-Seat Assembly to Armrests using  
 1 - 3 1/2" Wafer Bolt  
 1 - 2 1/2" Wafer Bolt &  
 1 - 2" Wafer Bolt per side,  
 be sure to match all letters, tighten  
 Wafer Bolts with included Hex Key.



8. Attach Lintels to Armrest Assemblies  
 using 4 - 2" Screws per side, be sure  
 to match all letters.



5' Classic Poly Glider Assembly Instructions

11/12/ 2024

R.M.