



Hardware


- 2 - 5/16" x 3 1/2" Stainless Wafer Bolts
- 2 - 5/16" x 2 1/2" Stainless Wafer Bolts
- 8 - 5/16" x 2" Stainless Wafer Bolts
- 4 - Lock Nuts
- 4 - Washers
- 12 - 3" Stainless Steel Screws
- 8 - 2 1/2" Stainless Steel Screws
- 32 - 2" Stainless Steel Screws
- 1 - 5/32 Hex key

Tools Required


5/32 Hex Key (Included)








#2 Square Drive Bit (Not Included)




9/16" Wrench (Not Included)




Cordless Drill (Not Included)




1. Attach Back Crosspiece (Short) and Front Crosspiece (Long) to Glider Base's Using 8 - 2" and 6 - 3" Screws per side, be sure to match all letters.





2. Attach Crosspiece Supports to Front-Back Crosspieces using 4 - 2" Screws per side, be sure to match all letters.



3. Attach Bearing Arm Supports to Glider Base using 4 - 2 1/2" Screws per side, Note: Install Aluminum facing towards back and down in Base Assembly. be sure to match all letters.



4. Attach Armrests to Glider Base using 2-Washers & 2-Nuts per side, be sure to match all letters. "Assembly order is Armrest Assembly-Washer-Nut"



Aluminum




5' Plain Poly Glider Assembly Instructions

11/12/ 2024


R.M.




5. Attach Back Assembly to Seat Assembly using 6 - 2" Wafer Bolts, be sure to Match all letters, tighten Wafer Bolts with included Hex Key.



6. Attach Back-Seat Assembly to Armrests using
 1 - 3 1/2" Wafer Bolt
 1 - 2 1/2" Wafer Bolt &
 1 - 2" Wafer Bolt per side,
 be sure to match all letters, tighten
 Wafer Bolts with included Hex Key.



7. Attach Lintels to Armrest Assemblies using 4 - 2" Screws per side, be sure to match all letters.



5' Plain Poly Glider Assembly Instructions

11/12/ 2024

R.M.