



#### Tools Required


5/32 Hex Key (Included)



1/2" Wrench  
(Not Included)



#2 Square Drive Bit  
(Not Included)





Cordless Drill  
(Not Included)




#### Hardware

- 2 - 5/16" x 3 1/2" Stainless Wafer Bolts
- 2 - 5/16" x 3" Stainless Wafer Bolts
- 8 - 5/16" x 2" Stainless Wafer Bolts
- 8 - 5/16" Nuts
- 12 - Washers
- 4 - 2" Screws
- 4 - 1 1/2" Screws
- 1 - Set Swing Chains
- 1 - 5/32" Hex Key

Armrest Assemblies x2




**1. Attach Back Assembly to Seat Assembly using 8 - 2" Wafer Bolts, Be sure to match all letters, Tighten Wafer Bolts with included Hex Key.**



2" Wafer Bolt

**2. Attach Armrest Assemblies to each side using 1 - 3 1/2" Wafer Bolt 1 - 3" Wafer Bolt 4 - Washers & 2 Nuts per side. :Insert Bolts from inside out: Tighten Wafer Bolts With Included Hex Key. Be sure to match all letters.**




Wafer Bolt requires Washers between product & Nut.

3" Wafer Bolt

3 1/2" Wafer Bolt



**3. Install 2 - 2" Screws & 2 - 1 1/2" Screws per side.**



1 1/2" Screw

2" Screw

**4. Attach short end of Chain to back of Armrest assemblies & other end through screw eye to bottom of front upright using 4 Washers & 2 nuts per side.**



5' Plain Poly Swing Assembly Instructions

11/12/ 2024

R.M.