

BERLIN  
GARDENS

# Comfo Back & Cozi Back Three Seat Glider Assembly Guide



## Hardware Included

8 - 5/16" x 2" Bolts  
8 - 5/16" x 2 1/2" Bolts  
2 - 1/4" x 4 1/2" Bolts  
2 - 1/4" x 3 1/2" Bolts  
8 - 1/4" x 3" Bolts  
12 - 5/16" Flange Nuts  
8 - 5/16" Lock Nuts  
4 - 5/16" Cap Nuts  
4 - 5/16" Aluminum Spacers  
12 - 1/4" Flange Nuts  
4 - Glider Brackets  
1 - Allen Wrench

## Tools Required



7/16" Wrench  
&  
1/2" Wrench




Allen Wrench  
(Included)



Hammer

## Step 1

A.  
Fasten the Arm and Leg Assembly to the Seat and Back using 1/4" bolts (sizes are specified below.)  
Using a hammer, firmly tap the bolts until they are flush with the poly surface. Securely tighten using 1/4" flange nuts.




B.  
Insert 5/16" x 2 1/2" bolts into the pre-drilled holes located at the very bottom of the legs. Tighten using 5/16" flange nuts. Ensure that the bolts are turned inwards.

C.  
Fasten the Back to the Seat using 2 - 1/4" x 3" bolts and tighten using 1/4" flange nuts.

D.  
Repeat A. & B. to fasten the second Arm and Leg Assembly to the Seat and Back


Back & Seat  
Attachment Detail

## Step 2




- A.  
Attach the two cross supports to the glider bases using 8 - 5/16" x 2" Bolts and 8 - 5/16" Flange Nuts.
- B.  
Attach the 4 - glider stops to the glider bases using 4 - 1/4" x 3" bolts and 4 - 1/4" Flange Nuts.

## Step 3



Attach the four glider brackets to the glider base by first sliding the bracket onto a 5/16" x 2 1/2" bolt. Next slide a round 5/16" aluminum spacer onto the bolt and insert the bolts into the pre-drilled holes of the glider base. Firmly tighten with a 5/16" lock nut and place a 5/16" cap nut at the end of the bolt sequence.

## Step 4



Slide the Base Assembly underneath the seat of the glider, ensuring the front of the base is pointed forward. Insert the 5/16" x 2 1/2" bolts that are installed at the bottom of the glider legs, into the lower holes of the Glider Brackets. Securely tighten using 4 - 5/16" Lock Nuts.