



### Hardware


- 10 - 5/16" x 3" Stainless Wafer Bolts
- 12 - 5/16" x 2 1/2" Stainless Wafer Bolts
- 2 - 5/16" Stainless Lock Nuts
- 2 - Stainless Washers
- 1 - 5/32 Hex Key

### Tools Required


5/32 Hex Key (Included)



1/2" Wrench  
(Not Included)




Seat Assembly x1




Front legs  
Shortest x2



Back Legs x2




Armrest Assemblies x2




Middle Legs  
Longest x2




Back Assembly x1




1. Attach Front Legs to each side using 2 - 2 1/2" Wafer Bolts per side,  
Be sure to match all numbers,  
Tighten Wafer Bolts with included Hex Key.




2. Attach Middle Legs to each side using 2 - 2 1/2" Wafer Bolts per side,  
Be sure to match all numbers,  
Tighten Wafer Bolts with included Hex Key.



3. Attach Back Legs to each side using 2 - 2 1/2" Wafer Bolts per side, Be sure to match all numbers, Tighten Wafer bolts with included Hex Key.



4. Attach Armrest Assemblies to each side using 4 - 3" Wafer Bolts per side, Be sure to match all numbers, Tighten Wafer Bolts with included Hex Key.



5. Attach Back Assembly to Seat Assembly using 1 - 3" Wafer Bolt - 1 - Washer- 1 Nut per side, Be sure to match all numbers, Tighten Wafer Bolts with included Hex Key.

